

Ventilator Tip Sheet for non-Critical Care Respiratory Therapists and RT Extenders

Karsten Roberts, Keith Lamb, Donna Tanner, Aaron Light, Tony Ruppert, Madison Fratzke, Eric Kriner, Jon Inkrott, and Carl Hinkson

This tip sheet assists non-Critical Care Respiratory Therapists and Respiratory Therapy extenders (RNs and APPs) who may be called upon to assist in a pandemic. *Disclaimer: This document is provided for informational purposes only and it does not replace formalized training or knowledge.*

Presentation

Patients with COVID-19 appear to have similar lung physiology to ARDS.

Acronyms

- VT - Tidal Volume, amount of air inhaled with each breath
- RR - Respiratory Rate
- PEEP - Positive End Exp. Pressure
- P_{PLAT} - Plateau Pressure
- Driving Pressure (DP) = P_{PLAT} - PEEP
- Trigger - what is needed to start breath delivery to the patient
- PIFR - Peak Inspiratory Flow Rate
- PIP - Peak Inspiratory Pressure
- MAP - Mean Airway Pressure
- T_I - Inspiratory time
- V_E - Minute Ventilation
- PBW - Predicted body weight
- F_{IO_2} - Fraction of inspired oxygen (0.21-1.0 or 21%-100%)

Other important considerations

- For guidance on the use of other modalities such as prone positioning, epoprostenol, ECMO, or other therapies for severe hypoxemic respiratory failure, please consult your local protocols or guidelines.
- For more information on the biology, epidemiology, diagnostics, treatment and lab values related to COVID-19 refer to: <https://onepagericu.com>

MODES OF MECHANICAL VENTILATION

Volume Control (VC)

- Settings: VT 4 - 6 mL/kg of PBW, RR 14 - 18 bpm, PEEP (see Table), T_I to achieve PIFR 40 - 60 L/min
 - Trigger: 2 - 5 L/min for Flow trigger, -2 cmH2O for Pressure trigger
 - Alarms: High Pressure 5-10 above PIP, V_E 50% above and below actual V_E
- ### Pressure Control (PC)
- Settings: Start at PIP 10-15 (adjust for VT goal), RR 14-18, PEEP (see Table), set T_I to ensure complete exhalation 1st, 2nd to make sure inspiratory flow waveform reaches baseline
 - Trigger: 2 - 5 L/min for Flow trigger, -2 cmH2O for Pressure trigger
 - Alarms: High Pressure 5 - 10 above PIP, V_E 50% above and below actual V_E

RULES OF PROTECTIVE LUNG VENTILATION

- Tidal volume setting: 4 - 6 mL/kg PBW (max 8 mL/kg)
 - PBW in kg = 50 + 2.3 (height in inches - 60)
 - PBW in kg = 45.5 + 2.3 (height in inches - 60)
- Keep plateau pressure \leq 30 cmH2O
 - Decrease VT by 1 mL/kg PBW if $P_{PLAT} > 30$ cmH2O
 - Measure P_{PLAT} after any changes
- Titrate F_{IO_2} to maintain SpO2 92-96%
- Maintain driving pressure < 15 cmH2O (Driving pressure = P_{PLAT} - PEEP)

Lower PEEP/higher FiO2

F_{IO_2}	0.3	0.4	0.4	0.5	0.5	0.6	0.7	0.7
PEEP	5	5	8	8	10	10	10	12

Consider low PEEP table for normal compliance/low driving pressure

F_{IO_2}	0.7	0.8	0.9	0.9	0.9	1.0
PEEP	14	14	14	16	18	18-24

Higher PEEP/lower FiO2

F_{IO_2}	0.3	0.3	0.3	0.3	0.3	0.4	0.4	0.5
PEEP	5	8	10	12	14	14	16	16

Consider high PEEP table for low compliance/high driving pressure

F_{IO_2}	0.5	0.5-0.8	0.8	0.9	1.0	1.0
PEEP	18	20	22	22	22	24

Mode Names on Different Vents

Drager E4 and XL

- VC = CMV, PC = PCV+Assist

Drager V500

- VC = VC-AC, PC = PC-AC

Servo-I and Servo-U

- VC = VC, PC = PC

PB 840 or 980

- VC = A/C VC, PC = A/C PC

Viasys Avea

- VC = Volume AC
- PC = Pressure AC

Hamilton (G5, C3)

- VC=(S)CMV, PC=PCV+, P-CMV

Management Based on ABG

- Normal ABG ranges
 - pH: 7.35 - 7.45
 - P_{aCO_2} : 35 - 45 mmHg
 - P_{aO_2} : 60 - 100 mmHg
- To decrease P_{aCO_2} : $\uparrow V_E$
 - Increase rate or VT
- To increase P_{aCO_2} : $\downarrow V_E$
 - Decrease RR or VT
- To change respiratory rate:
 - (Current $P_{aCO_2} \times$ Current RR) \div Desired P_{aCO_2} = new RR
- To increase P_{aO_2} : \uparrow PEEP by 2, and or $\uparrow F_{IO_2}$ by 10%
- Consider permissive hypercapnea to prevent ventilator induced injury, pH as low as 7.25